



1



2



3



4



5

1. The occigrip arms are attached at the front of the helmet
2. Carefully pull them out of the plastic attachment points, on both sides.
3. Now both arms are loose
4. Turn the T-bar bow at the back where the adjustment band is 90 degrees, where it is attached, it should come
5. Attachment point at the neck
6. Follow the same procedure in reverse to complete the repair