

## O-ring assembly on retention system

Below is an instruction on how to assemble the O-ring to the retention system of the following models: Trooper, Trooper MIPS, Trooper SL, Trooper SL MIPS, Switcher, Switcher MIPS, Igniter, Igniter MIPS, Grimmir MIPS, Rooster and Rooster LE

1. Take off the Chin Pad from the retention system



2. Thread the O-ring over the fidlock buckle and over the tension lock. The O-ring should be placed close to the tension lock



3. Assemble the Chin Pad on to the retention system

