



Interstellar Goggle strap replacement

1. Remove SP RIG lens from goggle. Remove goggle strap. Lift outrigger wings up, push goggle strap clip down, "click" noise on removal.



2. Outrigger arms are extended "up" push one end out at a time. Difficult if this is the first time it is done.



3. Once removed, replace with new outrigger arms. Hold outrigger in place and press down gently with thumb. Clicking in place.



⌘ On this step you might need to use a pliers to gently press together the small arms together, as the plastic could be shaped like a “Y”

- 4. Line up new goggle strap on each end. Hold the back end of the outrigger, both thumb press on each end clip of the goggle strap. Clicking in place.**



- 5. How it should look once completed. Then repeat on opposite end.**



Good job!

Get in contact with us if you have any difficulties: customerservice@sweetprotection.com